

## INSTALLATION INSTRUCTIONS FOR CHAINWHEEL NUMBER 0 AND 1

1. Place the plate over the valve stem in back of the valve hand wheel.



3. Follow step 2 to loosely secure the 2 remaining bolts, washers (if included), and nuts.



2. Place the chainwheel against the front of the valve hand wheel aligning the slots of the chainwheel to the holes in the plate. Put one washer (if included) on a bolt, pass the bolt through the top slot (12 o'clock) in the chainwheel from the front, and through the holes in the plate. Loosely secure with a washer (if included) and nut.



4. Center the chainwheel and tighten the nuts securely.

